# 1 WWLLN Service Unit v4 Initial Setup

#### Method 1: SSH Setup

The SSH setup method requires:

- Ethernet cable
- SSH capable computer
- 1. Connect SU to a host computer directly with an ethernet cable
- 2. Set host computer ethernet network settings to:

address: 192.168.10.1 gateway: 192.168.10.100 netmask: 255.255.255.0

3. SSH into the SU from host computer:

```
ssh -p 7777 sferix@192.168.10.2
password: [ ]
```

- 4. Set desired static ip configuration in file  $\sim$ /networkSetup.sh
- 5. sudo ./networkSetup.sh
- 6. Switch SU to main network ethernet within 1 minute of running networkSetup.sh
- 7. Test connection by SSH'ing into SU with new IP address
- 8. (a) If successful: set new IP setting in /etc/network/interfaces
  - (b) If unsuccessful: power cycle SU and check settings starting with step 3
- 9. Reset SU and confirm new settings

## Method 2: Workstation Setup

The Workstation setup method requires:

- HDMI Monitor and cable
- Powered USB Hub
- USB Keyboard
- USB Mouse
- 1. Connect an HDMI display, keyboard and mouse
- 2. Set network information through GUI

# Website Setup

#### Starting apache2

To get apache2 running only one change needs to be made in the /etc/apache2/httpd.conf file.

Line 96: #ServerName www.example.com:80

Needs to be uncommented and changed to the hostname of the computer, e.g.:

Line96: ServerName bobholz-3.ess.washington.edu:80

Then either the SU needs to be restarted or httpd and apach2 need to be restarted:

sudo httpd -k restart
sudo /etc/init.d/apache2 restart

## Setting up the website

All changes to the website need to be made in the /home/sferix/public\_html\_static folder, this folder is copied to /home/sferix/public\_html during start up. Changes to public\_html are not saves as the folder is located in system RAM due to SD card read/write limitations. A restart in not necessary if the public\_html\_static contents are copied to public\_html.