WWLLN Service Unit v4 Initial Setup

Method 1: SSH Setup

The SSH setup method requires:

- Ethernet cable
- SSH capable computer
- 1. Connect SU to a host computer directly with an ethernet cable
- 2. Set host computer ethernet network settings to:

address: 192.168.10.1 gateway: 192.168.10.100 netmask: 255.255.255.0

3. SSH into the SU from host computer:

```
ssh -p 7777 sferix@192.168.10.2 password: []
```

- 4. Set desired static ip configuration in file \sim /networkSetup.sh
- 5. sudo ./networkSetup.sh
- 6. Switch SU to main network ethernet within 1 minute of running networkSetup.sh
- 7. Test connection by SSH'ing into SU with new IP address
- 8. (a) If successful: set new IP setting in /etc/network/interfaces
 - (b) If unsuccessful: power cycle SU and check settings starting with step 3
- 9. Reset SU and confirm new settings

Method 2: Workstation Setup

The Workstation setup method requires:

- HDMI Monitor and cable
- Powered USB Hub
- USB Keyboard
- USB Mouse
- 1. Connect an HDMI display, keyboard and mouse
- 2. Set network information through GUI